CMI700 Series

Control your plating/coating process with the most advanced bench-top system that we have ever designed

CMIZOO

Ergonomic design, a large backlit LCD display, and Oxford Instruments technology and experience have been brought together to produce the **CMI**700 Series. This easy-to-use microprocessor driven instrument delivers precise measurements at the touch of a button. Specially designed to handle the needs of platers, coaters, and quality professionals, the **CMI**700 was built to withstand even the most hostile work environments.

The **CMI**700 combines ease-of-use with high inspections productivity and accuracy with a display that is clearly visible

from several feet away and from virtually any angle.

The **CMI**700 provides high tech solutions for non-destructive coating/plating thickness measurement for both non-magnetic coatings over magnetic substrates, non-conductive coatings over conductive substrates, and electroplated nickel over magnetic substrates.

Like all our instruments, it's backed by the Oxford Instruments Group. We guarantee superior service before and after your order.

- Platers: Zn, Cd, Ni, Cu etc
- **Coaters: Paint, Powder and Anodize**

Quality: Ideal for incoming inspection of coated or plated parts



CMI700 Series coating thickness measurement system



Backlit Screen

Eddy Current Mode	Range	Magnetic Mode
Non-Conductive on Conductive	0-40.0 mils (0-1000 μm)	Non-Magnetic on Magnetic Steel
Zinc on Steel	0-1.50 mils (0-37.5 µm)	
Cadmium on Steel	0-1.50 mils (0-37.5 μm)	Electroplated Nicko on Non-Magnetic
Copper on Steel	0-1.50 mils (0-37.5 µm)	
Nickel on Steel	0-3.00 mils (0-75.0 μm)	

Probe Samples and Information



Probes are required with all CMI700 Series systems. Despite their size and simple appearance, probes are high precision electromechanical assemblies that play a critical role in your ability to measure parts accurately.

USA Chicago, Illinois Tel: +1 800 678 1117 Fax: +1 847 439 4425 Email: sales@msys.oxinst.com www: oxford-instruments.com

© Oxford Instruments Analytical Limited, 2002. All rights reserved.

	Magnetic Mode	Range
µm)	Non-Magnetic on Magnetic Steel	0-50.0 mils (0-1250 μm)
ım)		
ım)	Electroplated Nickel on Non-Magnetic	0-5.00 mils (0-125 μm)

The Oxford Instruments Support team will help you select the probe that will measure your application. Factors involved in probe selection are type of coating, thickness of coating, size of part, and shape of part. **Optional probe** guides provide precision control.



Probe Guide (optional)

CMI700 Series Specifications

Magnetic Induction: Conforms to methods ASTM B499 & B530, DIN 50981, ISO 2178 and BS 5411 Parts 9 & 11

Eddy Current: Conforms to methods ASTM B244 & B259, DIN 50984, ISO 2360 and BS 5411 Part 3

Memory: 8000 bytes, non volatile

Accuracy: $\pm 1\% \pm 0.1 \mu m$ referred to reference standards

Outputs: Parallel printer port and RS232 serial port

Unit Conversions: Select from mils, µm, µin, mm, in., or % as units for display

Weight: 6 Lbs. (2.79 kg)

Dimensions: (W) 11.5" (29.21 cm) (D) 10.5" (26.67 cm) (H) 5.5" (13.97 cm)

Display: Large LCD 480(H) x 320(V) pixels, backlit, wide angle view

Statistics: Mean, high and low, standard deviation, % deviation and CPK

Charts: Histogram, trend, x-Bar and r

Call Sales Support for more information regarding the CMI700 Series.

CMI700 Series instruments comply with ISO/IEC Guide 25 requirements.

Multiple Security Levels

CE Mark

This publication is the copyright of Oxford Instruments Analytical Limited and provides outline information only which (unless agreed by the company in writing) may not be used, applied or reproduced for any purpose or form part of any order or contract or be regarded as a representation relating to the products or services concerned.

Oxford Instruments' policy is one of continued improvement. The company reserves the right to alter without notice the speci-fication, design or conditions of supply of any product or service. Oxford Instruments acknowledges all trademarks and registra-



OIA/52/A/0202